Micro-Embedded Generation Facility Connection Agreement

In consideration of the Local Distribution Company (LDC) agreeing to allow you to connect your 10 kW name-plate rated capacity or smaller generation facility to the LDC's distribution system, you hereby agree to the following terms and conditions.

1. Eligibility

1.1. You agree that your generation connection shall be subject to all applicable laws and bound by the terms and conditions of the LDC's Conditions of Service as amended from time-to-time, which have been filed and with the OEB and are available on request.

2. Technical Requirements

- 2.1. You represent and warrant that you have installed or will install prior to the connection of your generation facility to the LDC's distribution system, an isolation device satisfying Section 84 of the Ontario Electrical Safety Code and agree to allow the LDC's staff access to and operation of this as required for the maintenance and repair of the distribution system.
- 2.2. You agree to perform regular scheduled maintenance to your generation facility as outlined by the manufacturer in order to assure that connection devices, protection systems, and control systems are maintained in good working order and in compliance with all applicable laws.
- 2.3. You agree that during a power outage on the LDC system your generation facility will shut down, unless you have installed special transfer and isolating capabilities on your generation facility. You agree to the automatic disconnection of your generation facility from the LDC's distribution system, as per the generator protective relay settings set out in this Agreement in Appendix A, in the event of a power outage on the LDC's distribution system or any abnormal operation of the LDC's distribution system.
- 2.4. You covenant and agree that the design, installation, maintenance, and operation of your generation facility are conducted in a manner that ensures the safety and security of both the generation facility and the LDC's distribution system.
- 2.5. Due to the LDC's obligation to maintain the safety and reliability of its distribution system, you acknowledge and agree that in the event the LDC determines that your generation facility (i) causes damage to; and/or (ii) is producing adverse effects affecting other distribution system customers or the LDC's assets, you will disconnect your generation facility immediately from the distribution system upon direction from the LDC and correct the problem at your own expense prior to reconnection.

3. Liabilities

- 3.1. You and the LDC will indemnify and save each other harmless for all damages and/or adverse effects resulting from either party's negligence or willful misconduct in the connection and operation of your generation facility or the LDC's distribution system.
- 3.2. The LDC and you shall not be liable to each other under any circumstances whatsoever for any loss of profits or revenues, business interruptions losses, loss of contract or loss of goodwill, or for any indirect, consequential, incidental or special damages, including but not limited to punitive or exemplary damages, whether any of the said liability, loss or damages arise in contract, tort or otherwise.

4. Compensation and Billing

- 4.1. If you are not an embedded retail generator, you agree that, subject to any applicable law:
 - a. the LDC will not pay you for any excess generation that results in a net delivery to the LDC between meter reads; and
 - b. there will be no carryover of excess generation from one billing period to the next unless you are, at the relevant time, a net metered generator (as defined in section 6.7.1 of the Distribution System Code).
- 4.2. If you are an embedded retail generator selling output from the embedded generation facility to the Ontario Power Authority under contract, you agree that the LDC will pay you for generation in accordance with the Retail Settlement Code.

4.3. If you are an embedded retail generator delivering and selling output to the LDC, you agree that the LDC will pay you for generation in accordance with the Retail Settlement Code.

5. Termination

5.1. You understand that you have the right to terminate this agreement at any time, and that by doing so you are required to disconnect your generation facility and notify the LDC of such action.

6. Assignment

6.1. You may assign your rights and obligations under this Agreement with the consent of the LDC, which shall not withhold its consent unreasonably. The LDC shall have the right to assign its rights and obligations under this Agreement without your consent.

Nameplate Rating of Generator:kW (example: Inverter Rating)	Total Installed Generation: (example: Solar Array Rating)	kW
Type: Wind Turbine Photovoltaic (Solar)	Hydraulic Turbine] Fuel Cell
Inverter Utilized: Yes No		
Inverter Certification: C22.2#107.1 UL 1741	Site Certified by ESA	

I confirm that the above information is true and accurate and I understand, accept and agree to comply with and be bound by the above terms and conditions governing the connection of my generation facility to the LDC's distribution system.

Address:		
Name: Print name and LDC account ho	Ider Accourt	nt # LDC Account Number
LDC Account Holder's Signature:		Date:
For ENWIN use only: StationFe	eder D	ate Connected

Appendix A – Generator Protective Relay Settings

Table 1 - Invertor Based Generation

The following relay settings shall be used for inverters built to the CSA standard:

System Voltage Vn 'V nominal V (Volts)	Frequency F (Hertz)	Maximum number of cycles to disconnect	
		Seconds	Cycles
V < 0.5 Vn	60	0.1	6
0.5 Vn ≤ V < 0.88 Vn	60	2	120
1.10 Vn ≤ V < 1.37 Vn	60	2	120
V ≥ 1.37 Vn	60	0.033	2
Vn	F < 59.5*	0.1	6
Vn	F > 60.5	0.1	6

Source: CSA C22.2 No. 107.1-01 Table 16

* The UL1741 & IEEE P1547 Standards use F < rated-0.7 i.e. 59.3 Hz.

To update if CSA C22.2 No. 107.1-01 is changed

Table 2 – Non-Invertor Generation

LDC's minimum requirements, for other generation are as follows:

System Voltage Vn 'V nominal V (Volts)	Frequency F (Hertz)	Maximum clearing time*	
		Seconds	Cycles
V < 0.5 Vn	60	0.16	9.6
0.5 Vn ≤ V < 0.88 Vn	60	2	120
1.10 Vn ≤ V < 1.20 Vn	60	1	60
V ≥ 1.20 Vn	60	0.16	9.6
Vn	F < 59.3	0.16	9.6
Vn	F > 60.5	0.16	9.6

* Clearing time is the time between the start of the abnormal condition

and the generation ceasing to energize the LDC's distribution system

- If you are uncertain about your generation equipment's protective relay settings, please check with your generating equipment supplier.
- Automatic reconnect setting time for your generator is after 5 minutes of normal voltage and frequency on the LDC's distribution system.